

ACCESSORIES



DUST CAPS & DUST PLUGS

Protective dust caps and dust plugs are available in molded rubber or metal in a variety of sizes. They should be used whenever possible to help reduce contamination of the hydraulic system and improve service life of the body half (coupling) and the mating tip half (nipple). A molded combination cap/plug is now available.



PART NUMBERS				
Coupler	Dust Cap (Protects Tip)		Dust Plug (Protects Body)	
	Steel	Molded	Steel	Molded
S10-2	S19-2	S19-2MR	S14-2	S14-2MR
S10-3	S19-3	S19-3MR	S14-3	S14-3MR
S10-4	S19-4	S19-4MR	S14-4	S14-4MR
S10-6	S19-6	S19-6MR	S14-6	S14-6MR
S10-8	S19-8	S19-8MR	S14-8	S14-8MR
S56-2	S59-2	S59-2MR	S54-2	S54-2MR
S56-3	S59-3	S59-3MR	S54-3	S54-3MR
S56-4	S59-4	S449-4M*	S54-4	S449-4M*
S56-6	S59-6	S59-6MR	S54-6	S54-6MR
S56-8	S59-8	S59-8MR	S54-8	S54-8MR
SF49-3	FF499-3		FF494-3	
FF49-3	FF499-3		FF494-3	
FF49-3M	FF499-3		FF494-3	
FF49-3-8	FF499-3		FF494-3	
FF49-3-1/2	FF499-3		FF494-3	
SH20-2(P)	S49-2	S449-2M*	S44-2	S449-2M*
SH20-14(P)	S49-2	S449-2M*	S44-2	S449-2M*
SH20-2-3P	S49-2	S449-2M*	S44-2	S449-2M*

PART NUMBERS				
Coupler	Dust Cap (Protects Tip)		Dust Plug (Protects Body)	
	Rubber & Steel	Molded	Rubber & Steel	Molded
S30-2P	S39-2		S34-2	
S30-3P	S39-3	S349-3M*	S34-3	S349-3M*
S20A-2(P)	S49-2	S449-2M*	S44-2	S449-2M*
S20-3(P)	S49-3	S449-3M*	S44-3	S449-3M*
S20-4(P)	S49-4	S449-4M*	S44-4	S449-4M*
S20-15(P)	S49-4	S449-4M*	S44-4	S449-4M*
S20-16(P)	S49-4	S449-4M*	S44-4	S449-4M*
S40-2(P)	S49-2	S449-2M*	S44-2	S449-2M*
S40-3(P)	S49-3	S449-3M*	S44-3	S449-3M*
S40-4(P)	S49-4	S449-4M*	S44-4	S449-4M*
S40-15(P)	S49-4	S449-4M*	S44-4	S449-4M*
S40-6(P)	S49-4	S449-4M*	S44-4	S449-4M*
S70-4(P)	S49-4	S449-4M*	S44-4	S449-4M*
S70-15(P)	S49-4	S449-4M*	S44-4	S449-4M*
S70-16(P)	S49-4	S449-4M*	S44-4	S449-4M*

*Molded Cap and Plug Color Designation:

M = Molded Black
 MB = Molded Blue
 MG = Molded Green
 MR = Molded Red

BREAK-AWAY CLAMPS

SafeWay's heavy-duty double break-away clamps allow one-hand connection when used with two-way sleeve style agricultural quick couplings. They also allow implement break-away when used with either one-way or two-way sleeve agricultural designs. Double break-away clamps are available for 3/8" and 1/2" body size agricultural quick couplings. Bulkhead mounting rings provide for bulkhead mounting (up to 1/8" thick) of our S40 Series and S70 Series female couplers.



S42-4



S42-3



S512-8

PART NUMBERS			
Complete Coupler	Assembled Clamp with No Couplers		Bulkhead Mounting Ring
	Cast Clamp	Formed Clamp	
S25-4(P)	S42-4		
S25-15(P)	S42-4		
S25-16(P)	S42-4		
S45-3(P)		S42-3	S43-3
S45-4(P)	S42-4		S43-4
S45-15(P)	S42-4		S43-4
S45-6(P)	S42-4		S43-4
S75-4(P)	S42-4		S43-4
S75-15(P)	S42-4		S43-4
S75-16(P)	S42-4		S43-4
		S77-4(P)	
		S77-15(P)	

BULKHEAD MOUNT

SafeWay's S51 Series tips can be bulkhead mounted by using a Bulkhead Flange Mount Kit.

PART NUMBERS	
Coupler	Bulkhead Flange Mount
S511-8	S512-8
S511-8-STL	S512-8
S511-10	S512-10
S511-10-STL	S512-10

REPLACEMENT SEALS & REPAIR KITS

Both replacement seal kits and individual O-rings and back-up rings are available. Leakage between the female body half (coupling) and the male tip half (nipple) is an indication that the body O-ring needs replacement.

Field repair kits that include the body seal, a new poppet assembly and installation instructions are available for various couplings.



PART NUMBERS			
Complete Coupler	O-ring	Back-up Ring	Field Repair Kit
S101-1			
S105-1	S1060B-1	S1061T-1	
S101-2			
S101-2-6			
S105-2	S1060B-2	S1061T-2	
S105-2-6	S1060B-2	S1061T-2	
S101-3			
S101-3-8			
S105-3	S1060B-3	S1061T-3	
S105-3-8	S1060B-3	S1061T-3	
S101-4			
S101-4-10			
S105-4	S1060B-4	S1061T-4	
S105-4-10	S1060B-4	S1061T-4	
S101-6			S106-6RK
S101-6-12			S106-6RK
S105-6	S1060B-6	S1061T-6	S106-6RK
S105-6-12	S1060B-6	S1061T-6	S106-6RK
S101-8			S106-8RK
S101-8-16			S106-8RK
S105-8	S1060B-8	S1061T-8	S106-8RK
S105-8-16	S1060B-8	S1061T-8	S106-8RK
SH25-2(P)	S460-2		
SH25-14(P)	S460-2		
SH25-2-3P	S460-2		
S35-2P	S360-2	S361-2	
S35-3P	S360-3	S361-3	
S511-6-1/2(-STL)			S511-6RK
S515W-6-1/2(-STL)			S515-6RK
S515H-6-1/2(-STL)			S515-6RK
S511-6(-STL)			S511-6RK
S515W-6(-STL)			S515-6RK
S515H-6(-STL)			S515-6RK
S511-8(-STL)			S511-8RK
S515W-8(-STL)			S515-8RK
S515H-8(-STL)			S515-8RK
S511-10(-STL)			S511-10RK
S515W-10(-STL)			S515-10RK
S515H-10 (-STL)			S515-10RK
S561-2			
S565-2	S5660B-2	S5661T-2	
S561-3			
S561-3-6			
S565-3	S5660B-3	S5661T-3	
S565-3-6	S5660B-3	S5661T-3	
S561-4			
S561-4-8			
S561-4-10			

PART NUMBERS			
Complete Coupler	O-ring	Back-up Ring	Field Repair Kit
S565-4	S5660B-4	S5661T-4	
S565-4-8	S5660B-4	S5661T-4	
S565-4-10	S5660B-4	S5661T-4	
S561-6			S566-6RK
S561-6-12			S566-6RK
S565-6	S5660B-6	S5661T-6	S566-6RK
S565-6-12	S5660B-6	S5661T-6	S566-6RK
S561-8			S566-8RK
S561-8-16			S566-8RK
S565-8	S5660B-8	S5661T-8	S566-8RK
S565-8-16	S5660B-8	S5661T-8	S566-8RK
SF491-3			SF491-3RK
FF491-3			FF491-3RK
FF491-3-8			FF491-3RK
FF491-3-1/2			FF491-3RK
FF491-6			FF491-6RK
FF491-6-12			FF491-6RK
FFE491-4			FF491-6RK
FFE491-4-3/4			FF491-6RK
FFE491-4-10			FF491-6RK
FFE491-4-12			FF491-6RK
FFE491-6			FFE491-6RK
FFE491-6-1			FFE491-6RK
FFE491-6-16			FFE491-6RK
FFE491-8			FFE491-8RK
FFE491-8-20			FFE491-8RK
FFE491-8-114			FFE491-8RK
S25A-2(P)	S460-2		
S25-3(P)	S460-3		
S25-4(P)	S460-4		
S25-15(P)	S460-4		
S25-16(P)	S460-4		
S25F-6	S260-6		
S25-8P	S260-8		S206-8RK
S45-2(P)	S460-2		
S45-3(P)	S460-3		
S45-4(P)	S460-4		
S45-15(P)	S460-4		
S45-6(P)	S460-4		
S75-4	S760-4		
S75-15	S760-4		
S75-16	S760-4		
S25-4-20	S170-4		
S25-15-20	S170-4		
S25-4-21P	S160-4		
S25-16-21P	S160-4		

Complete Coupler Numbers shown with a parenthesis indicate alternative part configurations